

[Blade Problems Causes & Cures - Loss of Tension](#)

Published on Wednesday, 28 November 2012 15:36 | [Print](#) | [Hits: 7244](#) Image not readable or empty
Removes/writes configuration to template1d1abc/images/system/printButton.png

Loss of Tension

Diamond saw blades are designed to run true at a prescribed RPM. A blade that is overheated or suffers a shock such as being dropped can lose its tension. This causes the blade to wobble or flutter when used. In the event a blade has lost its tension it needs to be returned to the manufacturer for retensioning.